Mössbauer's spectroscopy applied on kaolinitic clays. Study of Fe³⁺ influences on final color of ceramic bodies (Originally published in JACS, 2005)

Jitka Třískova, Daniel Nižňanský (Charles Univerzity, Prague, Czech Republic)

Tomas Hanzlicek, Pavel Straka, Michaela Steinerova (Institute of Rock Structure and Mechanics, Academy of Sciences, Prague, Czech Republic)

Kaolin

- Name comes from Chines locality Kao-Ling (高嶺土) original meaning – "High Mountain Ridge"
- Material is used for the production of porcelain, paper, tires, medicaments etc.
- Basic material for all geopolymer reactions.
- Kaolin origins from feldspars
- Main component is kaolinite (accompanied by quartz, rests of feldspar, eventually micas and limited proportions of iron and titanium oxides).

Kaolinite

chemical composition: Al₂O₃ 2SiO₂ 2H₂O Double layered structure changing regularly the layers of tetrahedral (Si_2O_5) and octahedral $(Al_2(OH)_4)$ - Fe³⁺ izo-morphologically substitutes aluminum ion

Kaolin composition changes through the thermal treatment

Changes formulated by (Brindley and Nakahira-1959) and generally used in ceramic industry :

- 580 °C dehydration (– H₂O)
- 925 °C spinel (2Al₂O₃3SiO₂) +SiO₂
- 1050 °C mullite phases (2Al₂O₃2SiO₂)+SiO₂
- 1200 °C mullite (3Al₂O₃2SiO₂) +SiO₂

P.S. The ceramic technology never worked with changes at aluminum ion coordination after the loss of lattice waters and before the spinel appears.

Mullite



Fe³⁺ in kaolin

- Commonly used rules:
- Fe³⁺ changes color in clays [pink-red to dark brown].
- By the rising temperature color change to the darker shades.
- Industry of the porcelain production resolves the color problem by reduction atmosphere use during the firing. (Changing by this way the coloring ferric oxide to discoloring ferrous oxide).
- These rules and industrial experiences are not valid generally.

Study of waste kaolinic clay

- Clay "S2" supplied by EXIMOS a.s.
- Clay is by-product of washed sandstone beside getting white sand for glass production.
- Unfortunately clay has no farther use and fills the deposit ponds. [30000 t/year]
- Clay change color according to the treatment temperature.
- Raw material yellow (content of Fe₂O₃ = 2.57 wt.%)
- 750°C brick reddish
- 1000 °C light red
- 1100 °C white, slightly gray shade
- 1180 °C white

Mössbauer's spectroscopy

- Analysis by Mössbauer spectra:
- reflects resonant absorption and emission of <u>gamma rays</u> in <u>solids</u>.
- Typically, three types of <u>nuclear</u> interactions may be observed: isomer shift, also called <u>chemical shift</u> in the older literature; <u>quadrupole splitting</u>; and magnetic <u>hyperfine splitting</u>

Mössbauer's spectroscopy

- Isomer shift describing a shift in the resonance energy of a nucleus due to the transition of electrons
- Quadrupole splitting reflects the interaction between the nuclear energy levels and surrounding <u>electric field</u> gradient
- The ground to excited state transitions appear as two specific peaks in a spectrum, sometimes referred to as a "doublet".
- Magnetic hyperfine splitting Magnetic (hyperfine splitting) is a result of the interaction between the nucleus and any surrounding magnetic field. In the majority of cases only 6 peaks can be monitored in a spectrum produced by a hyperfine splitting (BHF).

Mössbauer's spectra of the raw material sample "S2"



	Subsp. 1	Subsp. 2
IS δ	0.30 mm/s	0.36 mm/s
QUA ∆E _Q	0.08 mm/s	0.58 mm/s

- Clay do not contain hematite
- Fe³⁺ in form of hydro ferric oxide (FeO(OH) lepidokrokite

Mössbauer's spectra clay "S2"

Sample fired at 750°C



	Subsp. 1	Subsp. 2
IS ð	0.37 mm/s	0.27 mm/s
QUA <i>AE</i> q	- 0.22 mm/s	0.46 mm/s
BHF	48.9 T	

- Lepidokrokite changes to hematite (Fe₂O₃)
- Color: brick red

Mössbauer's spectra clay "S2" explication

- Subspectrum 1 QS quadrupole splitting (The quadrupole splitting can be used for determining oxidation state),
- value (- 0.22) shows presence of α-Fe₂O₃ because no other iron oxide phase has negative value of QS.
- Subspectrum 2 shows the paramagnetic
 Fe³⁺ probably bonded to aluminosilicate.

Mössbauer's spectra clay "S2"

Sample fired at 1000°C



Color: Light red

Mössbauer's spectra clay "S2"

Sample fired at 1180°C



	Subsp. 1	Subsp. 2
IS ठ	0.33 mm/s	0.31 mm/s
QUA ΔE _Q	0.76 mm/s	1.21 mm/s

 Change of color discoloring
 Fe³⁺ totally incorporated into mullite lattice

Mossbauer's spectra clay "S2"

- We see the typical "doublet"—significant the presence of paramagnetic Fe³⁺ diluted in the aluminosilicate matrix at atomic level.
- Even the spectra shows the presence of Fe³⁺ ions, the incorporation means also discoloration.
- Following studies present limit of Fe³⁺content incorporated into the aluminosilicate matrix.

Study of red clay material

used for the floor tiles production

- Clay deposit "Zelec"
- Naturally dark red kaolinitic clay
- Content of Fe₂O₃ > 10.2 wt. %
- Color changes are practically invisible during firing:
- raw material dark red/brown
- 750 °C red but slightly lighter than raw material
- 1000 °C similar as above
- 1180 °C very dark red/brown color

Mössbauer's spectra clay "Zelec"

Raw material



	Subsp. 1	Subsp. 2
IS δ	0.30 mm/s	0.40 mm/s
QUA ΔE_Q	0.60 mm/s	- 0.23 mm/s
BHF		50.8 T

Clay contents
 hematite (α-Fe₂O₃)

Mössbauer's spectra clay "Zelec"

Sample fired at 750°C



Mössbauer's spectra clay "Zelec" Sample fired at 1000°C



	Subsp. 1	Subsp. 2
IS ō	0.28 mm/s	0.37 mm/s
QUA ΔE_Q	0.82 mm/s	-0.23 mm/s
BHF		49.7 T

 Hematite content still confirmed

Mossbauer's spectra clay "Zelec"

Sample fired at 1180°C



	Subsp. 1	Subsp. 2
IS δ	0.30 mm/s	0.37 mm/s
QUA ΔE _Q	1.10 mm/s	- 0.21 mm/s
BHF		49.3 T

 Hematite is not dissolved in aluminosilicate matrix

The ability of kaolinite to dissolve Fe³⁺

- Study on standard kaolin "Sedlec Ia" used in the production of Czech porcelain.
- Fe₂O₃ content lower than 1 wt. %
- Doped by $Fe(NO_3)_3$.9 H₂O gradually up to 5 wt. %
- Observed color changes during temperature rise:
- Presented results on samples with maximal iron content:
- 750 °C orange/red
- 1000 °C light skin pink
- 1180 °C very light, practically white

The ability of kaolin to dissolve Fe³⁺ ions

Doped Kaolin sample fired at 750°C



	Subsp.	Subsp.	Subsp.
	1	2	3
IS δ	0.33	0.35	0.38
	mm/s	mm/s	mm/s
QUA	1.27	0.78	- 0.21
ΔE _Q	mm/s	mm/s	mm/s
BHF			50.5 T

- Hematite confirmed

The ability of kaolin to dissolve Fe³⁺ ions Sample fired at 1000°C



	Subsp. 1	Subsp. 2
IS δ	0.27 mm/s	0.38 mm/s
QUA ΔE _Q	0.94 mm/s	- 0.19 mm/s
BHF		50.0 T

- Hematite still occures

The ability of kaolin to dissolve Fe³⁺ ions Sample fired at 1180°C



	Subsp
IS δ	0.31 mm/s
$QUA \Delta E_Q$	1.09 mm/s

 Hematite completely dissolved in aluminosilicates

Conclusions

- The content of Fe³⁺ ions is not the only determination of the final color of ceramic body.
- Significant is a form of Fe³⁺ ions: Hematite (Fe₂O₃) always means darker colors (orange, red and brown).
- Mössbauer's spectroscopy confirms incorporation of Fe³⁺ ions in aluminosilicate matrix.
- Discoloring effect is limited by maximal amount of Fe₂O₃ in clays (5 - 6 wt. %) and temperature exceeding 1180 °C.
- Hematite originated through the firing is highly reactive due to the small and very small particles.

Thank you for your attention